


HP20 G6

2011.10.14 →




HP20 G6

No.	Dansk	Deutsch	English	Français
166	Skrue	Schraube	Screw	Vis
175	Låsering	Seegerring	Lock ring	Circlips
375	Retteklods	Richtblock	Straightening block	Block de redressage
466	Møtrik	Mutter	Nut	Ecrou
559	Pumpehåndtag	Pumpenstange	Pump rod	Levier de pompe
655	Håndtag	Handgriff	Handle	Poignée
722	Fitting	Fitting	Fitting	Raccord
1031	Låseplade	Sicherungsblech	Lock plate	Plaque de verrouillage
1113	Håndtag	Handgriff	Handle	Poignée
2837	Manometer 20T	Manometer 20T	Manometer 20T	Manomètre 20T
2828	Skrue	Schraube	Screw	Vis
2854	Trykhoved	Kolbenkopf	Pistonhead	Tête de piston
2861	Nagle	Nagel	Rivet	Rivet
2863	Trykrør	Druckrohr	Pressure pipe	Tuyau de refoulement
2871	Hydraulik slange	Hydraulikschlauch	Hydraulic hose	Tube hydraulique
2897	Fitting	Fitting	Fitting	Raccord
2938	Luftventil	Luftventil	Air valve	Soupape d'air
3247	Bord	Tisch	Bench	Table
3312	Skive	Scheibe	Washer	Goupille
3330-1	Chassis (Grøn)	Chassis (Grün)	Chassis (Green)	Chassis (Vert)
3330-12	Chassis (Rød)	Chassis (Rot)	Chassis (Red)	Chassis (Rouge)
5533	Manometerrør	Rohr f. Manometer	Pipe f. manometer	Tuyau p. manomètre
850456	Skrue	Schraube	screw	Vis
872995	Reduktionsventil	Druckminderventil	Reducing Valve	Détendeur
928174	Pumpe, komplet	Pumpe, komplett	Pump, complete	Pompe, complet
928122	Cylinder, komplet	Zylinder, komplett	Cylinder, complete	Cylindre, complet
060085	Pakningssæt, komplet	Dichtungssatz, komplett	Repair kit, complete	Jeu de réparation, complet

928176

(PP20/25HP G5/6)




928176

(PP20/25HP G5/6)

No.	Dansk	Deutsch	English	Français
*18	Kobberpakning	Kupferdichtung	Copper washer	Disque en cuivre
*19	Ventilkugle, 8 mm	Ventilkugel	Valve ball	Boule de clapet
106	Pumpestempel	Pumpenkolben	Pump piston	Piston de pompe
*107	Manchet	Manschette	Sleeve	Bague
*108	Messingring	Messingring	Brass ring	Rondelle en laiton
*109	Låsering	Sicherungsring	Lock ring	Circlips
*111	Simmerring	Simmerring	Simmer ring	Rondelle simmer
112	Pakdåse	Stopfbüchse	Stuffing box	Ecrou piston
*113	Pakning	Dichtung	Gasket	Joint d'étanchéité
114	Returspindel	Ablaßspindel	Return spindle	Pivot de retour
115	Fjeder	Feder	Spring	Ressort
116	Møtrik	Mutter	Nut	Ecrou
*117	Kugle, 5 mm	Kugel	Ball	Boule
118	Returventil, kompl.	Ablassventil, kompl.	Return valve, compl.	Clapet de retour, compl.
120	Låsering	Sicherungsring	Lock ring	Circlips
*522	O-ring	O-Ring	O-ring	Joint torique
642	Pakdåse	Stopfbüchse	Stuffing box	Ecrou de piston
643	Pumpestempel, kompl.	Pumpenkolben, kompl.	Pump piston, compl.	Piston de pompe, compl.
659	Mellemlid	Zwischenglied	Connecting link	Bielle en fourche
*672	Ventilkugle, 3/8"	Ventilkugel	Valve ball	Boule de clapet
1113	Håndtag	Handgriff	Handle	Poignée
1971	Klemskive	Scheibe	Disc	Disque
2187	Fitting	Fitting	Fitting	Raccord
2327	Luftfitting	Fitting f. Luft	Air fitting	Raccord pneumatique
2439	Nagle	Nagel	Rivet	Rivet
2624	Skive	Scheibe	Washer	Goupille
2795	Nitte	Niet	Rivet	Rivet
2840	Udløserbøjle	Beschlag	Mountings	Bras de déclenchement
2841	Nagle	Nagel	Rivet	Rivet
3621	Nippel	Nippel	Nipple	Raccord
60090	Pakningssæt	Dichtungssatz	Repair kit	Jue de joint
*	Indeholdt i pakningssæt 60090	Im Dichtungssatz 60090 enthalten	Contained in the repair-kit 60090	Contenu dans le jeu de joint 60090


928122

(PC20 G5/G6)




No.	Dansk	Deutsch	English	Français
*501	O-ring	O-ring	O-ring	Joint torique
*818	O-ring	O-ring	O-ring	Joint torique
*819	O-ring	O-ring	O-ring	Joint torique
846	Fitting	Fitting	Fitting	Raccord
2327	Fitting	Fitting	Fitting	Raccord
2668	Pakdåse	Stopfbüchse	Stuffing box	Ecrou piston
*2669	Føringsbånd	Buchse	Bushing	Douille
*2670	Føringsbånd	Buchse	Bushing	Douille
2828	Skrue	Schraube	Screw	Vis
2854	Trykhoved	Kolbenkopf	Pistonhead	Tête de piston
*2868	Glydring m. O-ring	Führungsring m. O-ring	Guidering w. O-ring	Joint annulaire et torique
2965	Fitting	Fitting	Fitting	Raccord
5350	Stempel	Kolben	Piston	Piston
60091	Pakningssæt	Dichtungssatz	Repair-kit	Jeu de réparation
*	Indeholdt i 60091	Im 60091 enthalten	Contained in the 60091	Contenu dans le jeu de joint 60091

HP/FP20 G6 (Air system diagram)





HP/FP20-25 G6 (Air system parts list)

2938



Indgår kun i HP model
Nur für die HP Modell verwendet
Only used for HP model
Uniquement utilisé pour le modèle HP



(HP/FP 20-25 G6)

No.	Dansk	Deutsch	English	Français
2872	Ventil	Ventil	Valve	Soup ape
2873	Fitting	Fitting	Fitting	Raccord
2875	Lyddæmper	Schalldämpfer	Sound absorber	Sourdine
2876	Slange Sæt	Schläuch Satz	Hose Kit	Tube
2879	Slangenippel	Stutzen f. Schlauch	Pipe branch	tubulure p. tube
2938	Luftventil	Luftventil	Air valve	Soupape d'air
3602	Fodpedal	Fusspedal	Pedal	Pédale
3603	Glider	Scheiber	Support	Support
3604	Møtrik	Mutter	Nut	Ecrou
3605	Skærm f Ventil	Blech f Ventil	Sheet f Valve	Plaque
3606	Skrue Komplet	Schraube Komplet	Screw complete	Vis Complet
3607	Monterings plade	Montage Blech	Bracket	Support
3608	Skrue Komplet	Schraube Komplet	Screw complete	Vis Complet
3609	Skrue Komplet	Schraube Komplet	Screw complete	Vis Complet
3610	Holder	Halter	Bracket	Support
3611	Adabter	Zwichensockel	Adabter	Adapteur
3617	Skrue Komplet	Schraube Komplet	Screw complete	Vis Complet
3618	Holder f fodpedal	Halter f Fusspedal	Bracket f Pedal	Support de pédale
872876	Fitting	Fitting	Fitting	Raccord
872995	Reduktionsventil	Druckminderventil	Reducing Valve	Détendeur

2938 (Only for HP20-25 G5/6)

No.	Dansk	Deutsch	English	Français
2939	Fjeder	Feder	Spring	Ressort
2940	Skrue	Schraube	Screw	Vis
2941	Hus f. stift	Gehäuse f. Splint	Housing f. pin	Corps p. cheville
2942	Stift	Splint	Pin	Cheville
2964	Luftfitting	Fitting f. Luft	Air fitting	Raccord pneumatique
2992	Ventil	Ventil	Valve	Soupape