


A1,6T-77 G1




A1,6T-77 G1

Pos	No.	Dansk	Deutsch	English	Français
A	003723	Kørestang komplet	Fahrstange kompl.	Jack handle compl.	Levier de manoeuvre compl.
B	003737	Pumpeenhed komplet	Pumpen einheit kompl.	Pumpunit complete	Unité de pompage
1	003724	Luft kobling 1/8"	Luft kupplung	Quick coupling	Bille
2	003725	Kørestang	Fahrstange	Jack handle	Levier de manoeuvre
3	003726	Betjeningsventil	Steuer ventil	Operating valve	Soupape de commande
4	003727	Sikkerhedsventil	Sicherheitsventil	Safety valve	Soupape de sécurité
5	003728	Manifold	Mannigfaltig	Manifold	Collecteur
6	003729	Slangesæt	Schlauch set	Hose set	Tubulure pour tube
7	003731	Kørestangshovede	Kopf f. Pumpenhebel	Fork handle	Tête du levier de manoeuvre
8	000122	Fingerskrue	Rändelschraube	Knurled screw	Vis moletée
9	000135	Låsering Ø19	Sicherungsring	Lock ring	Circlips
10	000134	Aksel	Achse	Shaft	Axe
11	003732	Skive f. lås	Scheibe für Sperre	Disc for Lock system	Tranche pour serrure
12	003733	Udløsernav m. ring	Ablassnabe m. ring	Release hub w. ring	Moyeu de déclenchement
13	003701	Afstandsskive	Scheibe	Disc	Disque
14	000128	Møtrik ¼"	Mutter	Nut	Ecrou
15	002950	Skive	Scheibe	Disc	Disque
16	000131	Udløserarm	Abläßsarm	Release arm	Bras de déclenchement
17	001971	Klemskive	Scheibe	Disc	Disque
18	001970	Nitte	Niet	Rivet	Rivet
19	000127	Udløserstang	Auslösestange	Release arm	Galet de débrayage
20	002795	Nitte	Niet	Rivet	Rivet
21	003318BL	Drejehjul komplet	Schwenkrolle kompl.	Castorwheel compl.	Roue pivotante compl.
22	000956	Afstandsør	Distanzrohr	Distance pipe	Bouchonoise
23	000634	Aksel	Achse	Shaft	Axe
24	000254	Låsering Ø25	Sicherungsring	Lock ring	Circlips
25	003734	Compac logo	Compac logo	Compac logo	Compac logo
26	000142	Låsering Ø22	Sicherungsring	Lock ring	Circlips
27	000144	Aksel	Achse	Shaft	Axe
28	003628BL	Hjul	Rad	Wheel	Roue
29	000141	Aksel	Achse	Shaft	Axe
30	000002	Cylinder	Zylinder	Cylinder	Cylindre
31	003065	Returfeder	Rückfeder	Return spring	Ressort de rappel
32	003627	Løftearm	Hubarm	Lifting arm	Levier de evage
33	003626	Sattel	Sattel	Saddle	Selle

A1,6T-77 G1

34	000125	Låsering Ø12	Sicherungsring	Lock ring	Circlips
35	003757	Skrue	Schraube	Screw	Vis
36	003735	Dækplade	Verkleidung	Cover plate	Plaque de recouvrement
37	000639	Skrue	Schraube	Screw	Vis
38	003736	Skumpude	Schaumstoffpolster	Foam pad	Tampon de mousse
39	0000528	Olierør	Öhlrohr	Oil pipe	Conduite d'huile
40	000214	Bolt	Bolzen	Bolt	Boulon
41	003753	Fixtur	Vorrichtung	Fixture	Fixation
42	002933	Stift	Splint	Pin	Cheville
43	001802	Sænkebremse	Senkbremse	Oil valve	Frein d'huile
44	000451	Bolt	Bolzen	Bolt	Boulon
45	000466	Møtrik	Mutter	Nut	Ecrou
46	003756	Skrue	Schraube	Screw	Vis
47	002763	Fitting	Fitting	Fitting	Raccord

003737




Pos	No.	Dansk	Deutsch	English	Français
A	003742	Luftpumpe	Luftpumpe	Air pump	D'air pompe
B	003745	Returventil komplet	Ablassspindel	Return spindle	Pivot de retour
C	002415	Overtryksventil	Überdruckventil	Excess-pressure valve	Soupape de surpression
D	003746	Tank komplet	Behälter komplet	Complete tank	Réservoir complet
E	061141	Pakningssæt t. pumpe	Dichtungssatz f. Pumpe	Air pump seal kit	Jeu de réparation d'air pompe
F	0611140	Pakningssæt til tank	Dichtungssatz f. Behälter	Tank seal kit	Jeu de réparation d' réservoir

003737

Pos	No.	Dansk	Deutsch	English	Français
1	000086**	Kobberpakning	Kupferdichtung	Copper washer	Joint cuivre
2	003738#	Skrue	Schraube	Screw	Vis
3	003739	Dækplade for filter	Abdeckplatte für Filter	Coverplate for filter	Plaque de filtre
4	003740#	Filter	Filter	Filter	Filtre
5	003004	Fitting	Fitting	Fitting	Raccord
6	003741	Prop	Dübel	Dowel	Goujon
7	003743	Låsering Ø16	Sicherungsring	Lock ring	Circlips
8	000111*	Simmerring	Simmering	Washer	Rondelle simmer
9	003744*	Pakdåse	Stopfbüchse	Stuffing box	Ecrou de piston
10	000113*	Pakning	Dichtung	Gasket	Joint d'étanchéité
11	000115	Fjeder	Feder	Spring	Ressort
12	000116	Møtrik	Mutter	Nut	Ecrou
13	000114	Returspindel	Ablassspindel	Return spindle	Pivot de retour
14	000117*	Kugle	Kugel	Ball	Bille
15	002416	Skrue	Schraube	Screw	Vis
16	000523	O-ring	O-ring	O-ring	Joint torique
17	002340	Fjeder	Feder	Spring	Ressort
18	002405	Ventilkegle	Ventilkegel	Valve cone	Cône de soupape
19	003747	Udluftningsskrue	Entlüftungsschraube	Bleed screw	La vis de purge
20	003748*	Fjeder	Feder	Spring	Ressort
21	000018*	Kobberpakning	Kupferdichtung	Copper washer	Joint cuivre
22	003749	Ventilprop	Ventil stopsel	Valve cap	Valve bouchon
23	000020	Ventilprop	Ventil stopsel	Valve cap	Valve bouchon
24	000902*	Fjeder	Feder	Spring	Ressort
25	000019*	Kugle	Kugel	Ball	Bille
26	003750*	Tætningsskive	Dichtscheibe	Sealing disc	Disque d'étanchéité
27	003751	Olieprop	Ölshraube	Oil plug	Bouchon
28	003615	Fitting	Fitting	Fitting	Raccord
*		Indeholdt i pakningssæt til tank	In Dichtungssatz für Tank enthalten	Contained in seal kit for tank	Contenu dans le jeu de joint pour réservoir
#		Indeholdt i filterkit	Im Filtersatz enthalten	Contained in filter kit	Contenu dans le kit de filtrage
**		Indeholdt i pakningssæt til pumpe	In Dichtungssatz für Pumpe enthalten	Contained in seal kit for pump	Contenu dans le jeu de joint pour pompe

000002



Pos	No.	Dansk	Deutsch	English	Français
1	000009	Cylinder	Zylinder	Cylinder	Cylindre
2	000012*	Manchet	Manschette	Sleeve	Bague
3	000011	Stempel	Kolben	Piston	Piston
4	000607	Beskyttelsesmuffe	Schutzmanschette	Nylon protection	Manchon de protection
5	002770	Filter	Filter	Filter	Filtre
	060055	Pakningssæt	Dichtungssatz	Repair kit	Jeu de reparation
		000002 + 000957	000002 + 000957	000002 + 000957	000002 + 000957
	*	Indeholdt i pakningssæt	Im Dichtungssatz enthalten	Contained in repair kit	Contenu dans le jeu de joint