


CRK4



!!
 De angivne numre er udelukkende positionsnumre.
 Die angegebenen nummer sind positionsnummer ausschließlich.
 The numbers indicated are position numbers only.
 Les numeros indiqués sont de position uniquement.

05.2.4001

2008.06.01

CRK 4

Pos.	No.	DANSK.	DEUTSCH.	ENGLISH.	FRANÇAIS.
1	0CRKB0523-A	Forlængerrør 16"	Verlängerungs rohr	Extension pipe	Rallonge pour tuyau
2	0CRKB0524-A	Forlængerrør 12"	Verlängerungs rohr	Extension pipe	Rallonge pour tuyau
3	0CRKB0525-A	Forlængerrør 8"	Verlängerungs rohr	Extension pipe	Rallonge pour tuyau
4	0CRKB0526-A	Forlængerrør 4"	Verlängerungs rohr	Extension pipe	Rallonge pour tuyau
5	0CRKF0182	Trykhoved kileformet	Druckkopf	Pressure head	Tête de piston
6	0CRKF0183	Trykhoved vinkelfod	Druckkopf	Pressure head	Tête de piston
7	0CRKF0184	Trykhoved vinkel	Druckkopf	Pressure head	Tête de piston
8	0CRKF0181	Fod 90 grader	Fuss	Base	Base
9	0CRKF0180	Fod flad	Fuss	Base	Base
10	0CRKF0179	Saddel	Sattel	Saddle	Selle
11	0CRKB0013	Trykhoved gummi	Druckkopf	Pressure head	Tête de piston
12	0CRKB0467	Lynkobling	Schnellkupplung	Flash coupling	Connexion rapide
13	0CRKSR05A	Spreader	Werkzeug	Spreader	Instrument
14	0CRKRA404	Trykcylinder	Druckzylinder	Pressure cylinder	Cylindre
15	0CRKHS236	Slange	Schlauch	Hose	Tube
16	0CRKPA350	Pumpe	Pumpe	Pump	Pompe
17	0CRKG0026	Opbevaringskasse	Boxen	Box	Boîte
18	0CRKCP211	Kobling hun	kupplung	Koubling	Accouplement
19	0CRKCP212	Kobling han	kupplung	Koubling	Accouplement
	0CRKPA804-RK	Pakningssæt	Dichtungssatz	Repair kit	Jeu de rep.