

Skiving Tools for TH 2-9, TH 2-10-3PH und TH 2-13-3PH

Internal skiving tool for TH 2-9, TH 2-10-3PH and TH 2-13-3PH

Internal skiving tool
TH 2-9 and TH 2-10-3PH




A: Internal skiving knife

Size	Internal skiving tool (without knife) Part Number	Internal skiving knife Part Number
-6	TH2-12-NT-6	TH2-12NK-6
-8	TH2-12-NT-8	TH2-12NK-8
-10	TH2-12NT-10	TH2-12NK-1012
-12	TH2-12NT-12	
-16	TH2-12NT-16	TH2-12NK-1620
-20	TH2-12NT-20	
-24	TH2-12NT-24	TH2-12NK-2432
-32	TH2-12NT-32	

External skiving tool for TH 2-9 and TH 2-10-3PH


External skiving tool
TH 2-9 and TH 2-10-3PH



A: External skiving tool holder
B: Mandrel for external skiving
C: Holder for skiving tool
D: External skiving knife

Size	Mandrel Size Part Number	External skiving tool (without knife) Part Number	Additional arm Part Number	External skiving knife Part Number
-4	TH2-11M-4	short arm TH2-11ES	short arm TH2-11ES-1 TH2-10-3PH only	TH2-11EK
-6	TH2-11M-6			
-8	TH2-11M-8			
-10	TH2-11M-10			
-12	TH2-11M-12	long arm TH2-11EL	long arm TH2-11EL-1 TH2-10-3PH only	TH2-11EK
-16	TH2-11M-16			
-20	TH2-11M-20			
-24	TH2-11M-24			
-32	TH2-11M-32			

Internal and external skiving tool for TH 2-13-3PH



Skiving tool
A: Tooling holder complete
B: Mandrel for internal skiving
C: Holder for external skiving knife
D: External skiving knife
E: Internal skiving knife

Internal and external skiving tool TH 2-13-3PH	Size		Mandrel Size Part Number	Internal skiving knife Part Number	External skiving toolholder Part Number	Additional arm Part Number	External skiving knife Part Number
	-6	external	TH2-11M-6		TH2-11ES		TH2-11EK
		internal	TH2-12NT-6	TH2-12NK-6			
	-8		TH2-13M-8	TH2-12NK-8	TH2-13ET	short arm TH2-13ES-1	
	-10		TH2-13M-10	TH2-12NK-1012			
	-12		TH2-13M-12	TH2-12NK-1620			
	-16		TH2-13M-16				
	-20		TH2-13M-20				
	-24		TH2-13M-24	TH2-12NK-2432		long arm TH2-13EL-1	
	-32		TH2-13M-32				