

## **Port Connectors**


## **DP** Transmitter **Calibration Adapters** For fractional tube

Parker CPI<sup>™</sup>/A-LOK<sup>®</sup> adapters connect directly to the bleed port of a differential pressure transmitter so that the calibration process can be simplified. Two sizes of adapters (1/4-28 Thd., 5/16-24 Thd.) are available to fit the vent ports of Rosemount, Honeywell, and Foxboro DP transmitters. Both adapters are available in 316SS.

TRANSMITTER TYPE			PARKER PART NO.				INTERCHANGES WITH				
(1) Rosemoun	(1) Rosemount/Foxboro		4-2 ZH2LX-SS-D950373				_				
(2) Honeywell		4-	4-2 ZH2LX-SS-D940336				SS-400-1-0257				
(3) Rosemount/	(3) Rosemount/Yokogawa		4-2 ZH2LX-SS-D030297				SS-400-1-0253				
(4) ABB		4-	4-2 ZH2LX-SS-D030249				-				
STRAIGHT	INCHES										
					INCHE	S					
THREAD	A	В	C	D	E	S F	G	Н	J	HEX	
THREAD (1) 5/16-24	A 2.32	<mark>В</mark> 1.41	<b>C</b> .70	<b>D</b> 2.03			<b>G</b> .25	<mark>Н</mark> .06	J .41	HEX 1/2	
		-		-	E	F			-		
(1) 5/16-24	2.32	1.41	.70	2.03	Е .24	<b>F</b> .60	.25	.06	-	1/2	




Dimensions for reference only, subject to change.



Calibration Adapter for **Rosemount/Foxboro DP Transmitters** 





Calibration Adapter for Honeywell DP Transmitters

79