





aerospace climate control electromechanical filtration fluid & gas handling hydraulics pneumatics process control sealing & shielding





icountBS - Bottle Sampler

The portable solution to fluid contamination bottle sampling

icount	Park	
disting 1D	Dete	14
Entle-003	26/09/2000 09:35	
Bettle-002	26/09/C000.09:25	
mottle-001	22/09/2000 14:10	
Bottle-050	12/09/2008 10:25	
Bottle-079	12/09/2008 08:59	
Bottle-079	11/09/2000 11:55	
Bottle-077	30/09/2000 14:33	
Bottle-076	10/10/2008 14:15	
Eottle-075	10/10/2008 14:07	
Bottle-074	10/10/2008 13:55	
Bottle-073	10/10/2008 13:32	
Select AP	Class' Selector	6
Despisy Encouncil	As Trested	
Harriel Bases 1		



ENGINEERING YOUR SUCCESS.



Parker

The complete solution - industrial design combined with state of the art technology

The icountBS - Bottle Sampler from Parker with its innovative industrial design has been developed for customers looking for state of the art technology, attention to detail and the compactness of a permanent laboratory particle analysis model.

Combine this with on-board, laser based, leading edge technology to bring to all industries a truly revolutionary Particle Counter. The icountBS is a product from the next generation of Parker's fluid particle analysis and monitoring innovations.

The IBS features an easy to use interactive touch screen, environmentally controlled pressurized bottle chamber for air bubble suppression via an internal compressor pump, with automated door locking mechanism, sample tube cleaning sleeve minimizing contamination cross over, and an internal printer.

The icountBS benefits from Parkers knowledge and experience of providing bottle analysis equipment to the market over the last 15 years. This experience comes from selling market leading innovative solutions and by having front line condition monitoring products for all sectors of fluid analysis opportunities. The unit was at every stage developed with the customers voice in mind.











icountBS - Bottle Sampler Features & Benefits

- Quick sample bottle analysis with variable test time options from 15 second and volume capacities from 10ml.
- Repeatable and re-producible result performance to ISO4406:1999 and NAS1638 particle count distributions. For other calibration standards consult Parker CMC.
- On-board compressor and 'shop' air capability.
- Design concept allowing for portability. DC and rechargeable battery pack power options built in.
- Cost-effective and economical alternative solution to external laboratory services.
- 6 fixed channel size analysis.
- Fluid resistant touch type screen panel.
- Sample tube self cleaning sleeve minimizing contamination cross over.
- Internal thermal printer.



Analysing the test results

Once the automatic oil sample test has been completed, what next?

Solid contaminants in fluid power systems vary in size, shape, form and quantity. The most harmful contaminants are normally between 6 microns and 14 microns. The ISO code is the preferred method of reporting quantity of contaminants. The ISO code number corresponds to contamination levels relating to three sizes.

The first scale number represents the number of particles larger than 4µm(c) per 100 milliliters of fluid, the second number for particles larger than 6 μ m(c) per 100 milliliters of fluid and the third number for particles larger than 14 μ m(c) per 100 milliliters of fluid.

For example: An ISO code 20/18/14indicates that there are between 500,000 and 1,000,000 particles larger than 4μ m(c), and between 130,000and 250,000 particles larger than 6 μ m(c), and between 4,000 and 8,000particles larger than 14μ m(c).

icountBS reporting and data

In addition to the 'raw data' printout of ISO compliant data from the icountBS's on-board printer, icount Mini-lab described on page 7 offers the user the advantage of a 2-page report template providing hard copy data on ISO and NAS individual counts and average contamination results.



Component Cleanliness Guide

Suggested acceptable contamination levels for various hydraulic systems

	Target ntaminat class to 0 4406: 19	particle level				Sensitivity	Type of system	Typical components
4 µm(c)	6 µm(c)	14 µm(c)	4 µm(c)	6 µm(c)	14 µm(c)			
15	13	9	16,000	4,000	250	Super critical	Silt-sensitive control systems with very high reliability. Laboratory or aerospace	High performance servo valves
17	15	11	64,000	16,000	1,000	Critical	High performance servo and high pressure long life systems, e.g. aircraft, machine tools etc.	Industrial servo valves
18	16	13	130,000	32,000	4,000	Very important	High quality reliable systems. General machine requirements	Piston pumps, proportional valves, compensated flow controls
20	18	14	500,000	130,000	8,000	Important	General machinery and mobile systems. Medium pressure, medium capacity	Vane pumps, spool valves
21	19	15	1,000,000	250,000	16,000	Average	Low pressure heavy industrial systems, or applications where long life is not critical	Gear pumps, manual and poppet valves, cylinders
23	21	17	4,000,000	1,000,000	64,000	Main protection	Low pressure systems with large clearances	Ram pumps

Notes:

Tables have been generated by organisations in various industries.

Some of the tables are defined in cumulative counts, e.g. '>6 μ m' and others are represented as differential counts e.g. '6-14 μ m'. All μ m(c) refer to MTD distributions. All μ m references will refer to ACFTD distributions.

All standards are in counts per 100ml and provide easy methods for converting particle counts into limits that are simple

to interpret. By noting the requirements of the standard, particle counts can be accurately converted to contamination levels.



icount BS Product Specification

Principle of Operation	Laser based light obscuration							
Calibration Dust	MTD or ACFTD							
Dimensions	H=530 x W=190 (210 Door) x D=410 (mm)							
Weight	18Kg							
Mechanical Composition	Stainless steel 316, plated mild steel and aluminium							
Plastics Composition	Precision polyurethane RIM mouldings and ABS plastic							
Environmental Operating Temperature (Tested)	+5°C to + 60°C							
Operating RH range	20 – 85% (Tested at 30°C, no condensation)							
Storage Temperature	-40°C to + 90°C							
Storage RH range	10 – 90% (Tested at 30°C, no condensation)							
Channel Sizes	MTD - >4µ(c),>6µ(c),>14µ(c),>21µ(c),>38µ(c), >70µ(c) ACFTD - >2µ,>5µ,>15µ,>25µ,>50µ,>100µ							
Analysis Range	ISO 7 to 21, NAS 0 to 12							
Contamination Standards	MTD - ISO 4406:1999 & NAS 1638 ACFTD - ISO 4406:1987, ISO 4406:1991 & NAS 1638 For further contamination standards consult Parker CMC							
Calibration Standard	ISO MTD and ACFTD calibration to traceable ISO Standards. (Contact Parker CMC for further details).							
Fluid Management	Maximum single sample = 100ml Minimum single sample = 10ml							
Possible Test Configurations	User selectable from single test up to 5 tests per run (eg.1x100ml up to 5 x50ml per run)							
Pre-Test Flush Volume	Minimum = 10ml, Maximum = 100ml							
Viscosity Range	5 to 400 cSt							
Fluid Compatibility	Mineral oils, petroleum and hydrocarbon based fluids (consult manufacturer) and some esters (consult manufacturer).							
Sample Bottle Size	No specific bottle required. Maximum size = 75 (Dia) x 150 (H) mm. Maximum Volume = 250ml							
Memory Storage	500 Tests (capacity warning after 450 tests)							
Output Display	Backlight 256 Colour STN Transmissive							
Output Display Resolution	320 x 3(R.G.B)(H) x 240(W) dots							
Display Active Area	115(H) x 86(W) mm							
Data Input	Via icon driven resistive touch screen							
Printer	Thermal dot-line printing							
Printer Paper	Ø50mm – (57mm x 25mm)							
Test Certification	Calibration & Certificate of Conformity							
Power Supply	DC Output - 12V@ 6.60Amps, 80 watts max. AC Input - 100 to 240V @ 1.2Amps (50 - 60 Hz)							
Battery Power	2 Hours (recommended to be fully charged every 3 months)							
Battery Stand-By Time	1 month (then 1 hour of operation)							
Battery Fuse	6.3 Amps (anti-surge)							
Air pressure Source	3.5 bar internal Mini-compressor OR 7 Bar shop air							

Order your icountBS Now!



icountBS – Bottle Sampler Ordering Information

Key	Fluic	І Туре	Calib	oration	Future Option			Future Future Future Tran Option Option Option			ortation ase	Power Supply Region		
IBS	1	Mineral	1	ACFTD	0 Lab Unit		0	0)	1	0	None	0	UK
			2	MTD	1# Mini-lab Package		ge					Case	1	USA
	#	Contac	t Parker for details	r further									2	Europe
Key	Fluid	і Туре	Calib	Calibration		iture Option	Future Option	Future Option			Transport Case		Power S Reg	
IBS		1		2	0		0	0	1	1	0		0	
IBS		1		2		0	0	0	1	1	0		1	

0

0

n

Accessories	Part Number
250ml Sample Bottle	ACC6NW001
Sample Bottle Pack (50)	ACC6NW002
Vapour/Waste Bottle	ACC6NW003
Waste Bottle Folder	ACC6NW004
Printer Paper Reel (x1)	ACC6NW005
UK Power Supply	ACC6NW006
USA Power Supply	ACC6NW007
European Power	ACC6NW008
Transit Case	Contact Parker
1m Waste Tube (Clear)	ACC6NW009
1m Vapour Hose (Blue)	ACC6NW010
USB Memory Stick	ACC6NW011
icountBS CD Manual	ACC6NW012

2

IBS

WARNING – USER RESPONSIBILITY

0

2

FAILURE OR IMPROPER SELECTION OR IMPROPER USE OF THE PRODUCTS DESCRIBED HEREIN OR RELATED ITEMS CAN CAUSE DEATH, PERSONAL INJURY AND PROPERTY DAMAGE.

 This document and other information from Parker Hannifin Corporation, its subsidiaries and authorized distributors provide product or system options for further investigation by users having technical expertise.

 The user, through its own analysis and testing is solely responsible for making the final selection of the system and components and assuring that all performance, endurance, maintenance, safety and warning requirements of the application are met. The user must analyze all aspects of the application, follow applicable industry standards, and follow the information concerning the product in the current product catalogue and in any other materials provided by Parker or its subsidiaries or authorized distributors.

 To the extent that Parker or its subsidiaries or authorized distributors provide component or system options based upon data or specifications provided by the user, the user is responsible for determining that such data and specifications are suitable and sufficient for all applications and reasonably foreseeable uses of the components or systems.

Offer of sale

Please contact your Parker representation for a detailed 'offer of sale'.



= hymatik

Introducing the NEW icount 'Mini-lab' – The effective way of utilising your icountBS

How clean is your hydraulic system? Contamination Control is only an oil sample away with our easy, 3-Step fluid analysis service.



Obtain your sample of hydraulic oil.



Take the 2 minute off-line oil sample test.



View your results and run a report immediately.





Kit comprises: icountBS. Flat-pack trolley. 30 sample bottles. Optional Laptop/software/printer and cables



Parker Worldwide

AE – UAE, Dubai Tel: +971 4 8127100 parker.me@parker.com

AR – Argentina, Buenos Aires Tel: +54 3327 44 4129

AT – Austria, Wiener Neustadt Tel: +43 (0)2622 23501-0 parker.austria@parker.com

AT – Eastern Europe, Wiener Neustadt Tel: +43 (0)2622 23501 900 parker.easteurope@parker.com

AU – Australia, Castle Hill Tel: +61 (0)2-9634 7777

AZ – Azerbaijan, Baku Tel: +994 50 2233 458 parker.azerbaijan@parker.com

BE/LU – Belgium, Nivelles Tel: +32 (0)67 280 900 parker.belgium@parker.com

BR – Brazil, Cachoeirinha RS Tel: +55 51 3470 9144

BY – Belarus, Minsk Tel: +375 17 209 9399 parker.belarus@parker.com

CA – Canada, Milton, Ontario Tel: +1 905 693 3000

CH – Switzerland, Etoy Tel: +41 (0) 21 821 02 30 parker.switzerland@parker.com

CL – Chile, Santiago Tel: +56 2 623 1216

CN – China, Shanghai Tel: +86 21 5031 2525

CZ – Czech Republic, Klecany Tel: +420 284 083 111 parker.czechrepublic@parker.com

DE – Germany, Kaarst Tel: +49 (0)2131 4016 0 parker.germany@parker.com

DK – Denmark, Ballerup Tel: +45 43 56 04 00 parker.denmark@parker.com

ES – Spain, Madrid Tel: +34 902 33 00 01 parker.spain@parker.com

FI – Finland, Vantaa Tel: +358 (0)20 753 2500 parker.finland@parker.com

© 2009 Parker Hannifin Corporation. All rights reserved.

FR – France, Contamine s/Arve Tel: +33 (0)4 50 25 80 25 parker.france@parker.com

GR – Greece, Athens Tel: +30 210 933 6450 parker.greece@parker.com

HK – Hong Kong Tel: +852 2428 8008

HU – Hungary, Budapest Tel: +36 1 220 4155 parker.hungary@parker.com

IE – Ireland, Dublin Tel: +353 (0)1 466 6370 parker.ireland@parker.com

IN – India, Mumbai Tel: +91 22 6513 7081-85

IT – Italy, Corsico (MI) Tel: +39 02 45 19 21 parker.italy@parker.com

JP – Japan, Tokyo Tel: +(81) 3 6408 3901

KR – South Korea, Seoul Tel: +82 2 559 0400

KZ – Kazakhstan, Almaty Tel: +7 7272 505 800 parker.easteurope@parker.com

LV – Latvia, Riga Tel: +371 6 745 2601 parker.latvia@parker.com

MX – Mexico, Apodaca Tel: +52 81 8156 6000

MY – Malaysia, Shah Alam Tel: +60 3 7849 0800

NL – The Netherlands, Oldenzaal Tel: +31 (0)541 585 000 parker.nl@parker.com

NO – Norway, Ski Tel: +47 64 91 10 00 parker.norway@parker.com

NZ – New Zealand, Mt Wellington Tel: +64 9 574 1744

PL – Poland, Warsaw Tel: +48 (0)22 573 24 00 parker.poland@parker.com

PT – Portugal, Leca da Palmeira Tel: +351 22 999 7360 parker.portugal@parker.com **RO – Romania,** Bucharest Tel: +40 21 252 1382 parker.romania@parker.com

RU – Russia, Moscow Tel: +7 495 645-2156 parker.russia@parker.com

SE – Sweden, Spånga Tel: +46 (0)8 59 79 50 00 parker.sweden@parker.com

SG – Singapore Tel: +65 6887 6300

SK – Slovakia, Banská Bystrica Tel: +421 484 162 252 parker.slovakia@parker.com

SL – Slovenia, Novo Mesto Tel: +386 7 337 6650 parker.slovenia@parker.com

TH – Thailand, Bangkok Tel: +662 717 8140

TR – Turkey, Istanbul Tel: +90 216 4997081 parker.turkey@parker.com

TW – Taiwan, Taipei Tel: +886 2 2298 8987

UA – Ukraine, Kiev Tel +380 44 494 2731 parker.ukraine@parker.com

UK – United Kingdom, Warwick Tel: +44 (0)1926 317 878 parker.uk@parker.com

US – USA, Cleveland Tel: +1 216 896 3000

VE – Venezuela, Caracas Tel: +58 212 238 5422

ZA – South Africa, Kempton Park Tel: +27 (0)11 961 0700 parker.southafrica@parker.com

European Product Information Centre Free phone: 00 800 27 27 5374 (from AT, BE, CH, CZ, DE, DK, ES, FI, FR, IE, IT, NL, NO, PL, PT, RU, SE, UK, ZA)

Bulletin: FDCB419UK 04/2009



Parker Hannifin Ltd. Hydraulic Filter Division Europe Tel: +44(0)1842 763299 Email: EPIC@parker.com www.parkerhfde.com

Your local authorized Parker distributor