



Air Driven, High Pressure Liquid Pumps

Product Catalog

Catalog: 02-9326BE

April 2022

aerospace
climate control
electromechanical
filtration
fluid & gas handling
hydraulics
pneumatics
process control
sealing & shielding





ENGINEERING YOUR SUCCESS.



Table of Contents

Introduction	2
Pump Series Models	3
Drive Types	3
Quick Reference Guide	4
Pump Operation	5
Air Drive Section	5
Typical Pump Cut-away	6
Pump Special Features	7
ASL Series Pump	8
ACHL Series Pump	13
AFL Series Pump	16
AHL Series Pump	19

Introduction

Parker Autoclave Engineers has always been a large user of Air-over-Liquid pump technology and has a lifetime of experience using all variety of pumps in many different configurations. We have used this experience to develop a best-in-breed line of air-driven, high pressure pumps that are efficient to operate, simple in design, and will stand the test of time. Compared to other types of hydraulic pumps, they provide cost effective and energy saving benefits for many applications in the Oil and Gas, Chemical, Industrial and Research industries.

These pumps convert simple air pressure into high and ultra-high liquid pressures by utilizing a large area piston on the air side to move a small area plunger to compress the liquid into very high hydraulic pressures - as high as 60,000 psi (4137 bar). Some designs are for economy, some for manual use, some for low-flow & high pressure, some for high flow & medium pressure. Pumps like these are perfect for product testing, valve actuation, chemical injection and other applications that require intense pressure. When used in conjunction with a Hydraulic Intensifier (another PAE product) pressures to 150,000 psi (10,000 bar) are normal.

Parker Autoclave Engineers has been making pressure and corrosion test systems as well as high pressure laboratory reaction vessels for over 70 years.







Parker Autoclave





Pump Series Models



ASL Series:

- Standard Liquid Pump
- Pressures up to 60,000 psi (4137 bar)
- 6 inches in diameter air piston
- · Broad range of ratios
- · Single and Double Piston



ACHL Series:

- · ACL Series Pump with hand lever Air or Manually Driven
- Pressures up to 31,900 psi (2199 bar)
- Precise Pressure control operation, pump is spring returned
- · 3 inches in diameter air piston



AFL Series:

- · High Flow, High Pressure
- Pressures up to 5,000 psi (1035 bar)
- Flow up to 6.8 gpm (25 lpm)
- Dual Acting



AHL Series:

- High Flow up to 7.6 gpm (29 lpm)
- Pressures up to 22,500 psi (917 bar)
- · Approximately 10 inch diameter air piston
- Dual Acting

Drive Types



Catalog Number Example: ASL150-01







Quick Reference Guide

			Maximum	Displacement	Max.	Liquid	Connections		
Pump Type	Catalog Number	Pressure Ratio	Rated Outlet Pressure PSI (bar)	Per Cycle .in³ (cm³)	Flow GPM	Inlet	Outlet		
ASL Series - Air Driven Standard Size Liquid Pumps									
				5 00 (05 5)	F 0	4 II ENIDT	4 (OII ENIDT		
Prefill/Flushing	ASL10-01	1:11	1,600 (110)	5.22 (85.5)	5.0	1" FNPT	1/2" FNPT		
Low Pressure	ASL25-01	1:28	4,000 (276)	2.10 (34.4)	2.3	1/2" FNPT	1/2" FNPT		
Low Pressure	ASL35-01	1:39	5,600 (386)	1.50 (24.64)	1.3	1/2" FNPT	1/2" FNPT		
Test Pump	ASL60-01	1:70	10,000 (689)	0.84 (13.8)	.79	1/2" FNPT	1/2" FNPT		
Test Pump	ASL100-01	1:113	15,000 (1,034)	0.52 (8.5)	.48	1/2" FNPT	1/2" FNPT		
Test Pump	ASL150-01	1:150	21,500 (1,482)	0.39 (6.4)	.36	1/2" FNPT	1/4" F250C		
Test Pump	ASL250-01	1:265	38,400 (2,648)	0.22 (3.6)	.21	1/2" FNPT	1/4" F250C		
Test Pump	ASL400-01	1:398	57,700 (3,978)	0.14 (2.3)	. 14	1/2" FNPT	1/4" F250C		
Test Pump	ASL35-02	1:78	11,200 (772)	1.50 (24.64)	1.05	1/2" FNPT	1/2" FNPT		
Test Pump	ASL60-02	1:140	20,000 (1,379)	0.84 (13.8)	.63	1/2" FNPT	9/16" SF562CX		
Test Pump	ASL100-02	1:226	31,000 (2,137)	0.52 (8.5)	.37	1/2" FNPT	1/4" F250C		
Test Pump	ASL150-02	1:300	43,000 (2,965)	0.39 (6.4)	.28	1/2" FNPT	1/4" F250C		
Test Pump	ASL400-02	1:796	60,000 (4,137)	0.14 (2.3)	. 11	1/2" FNPT	1/4" F250C		
ACHL Series									
Compact/	ACHL72-01	1:84	12,500 (862)	0.09 (1.47)	. 17	3/8" FNPT	1/4" F250C		
Manual Pumps	ACHL189-01	1:213	31,900 (2,1990)	0.035 (0.57)	. 19	3/8" FNPT	1/4" F250C		
AHL Series									
	AHL33-2D	1:67	6,700 (462)	15.3 (250.7)	7.6	1" FNPT	1/2" FNPT		
Chemical	AHL66-2D	1:133	13,300 (917)	7.8 (127.8)	3.6	1/2" FNPT	1/2" FNPT		
Injection	AHL118-2D	1:239	22,500 (1551)	4.4 (72.1)	2.3	1/2" FNPT	9/16" SF562CX		
AFL Series									
	AFL35-1D	1:39	5,600 (386)	6.02 (98.7)	6.9	1" FNPT	9/16" SF562CX		
High Flow	AFL60-1D	1:70	10,000 (690)	3.40 (55.7)	3.9	1" FNPT	9/16" SF562CX		
Pumps	AFL100-1D	1:113	15,000 (1034)	2.30 (37.7)	2.9	1" FNPT	9/16" SF562CX		





Pump Operation

Piston to Plunger Ratio


- · Compressed air is used to produce hydraulic pressure
- Works on differential surface area between the large air piston and smaller hydraulic plunger
- Differential is represented by the pressure ratio of the pump

Pressure Ratio = Area of Air Piston ÷ Area of Hydraulic Plunger

• The higher the pressure ratio, the higher the output hydraulic pressure

Pressure Output = Pressure Ratio x Air Drive Pressure

- · When air is applied to the pump it will cycle until the forces on the air piston equals the forces on the hydraulic plunger. This is the stall pressure.
- Pump will automatically restart if there is a drop in hydraulic pressure or an increase in air drive pressure.
- Double air pistons available which will double the pressure ratio because you have twice the air piston area acting on the same hydraulic plunger area.



Air Drive Section


- · Compressed air is used to produce hydraulic pressure
- Works on differential surface area between the large air piston and smaller hydraulic plunger
- · Differential is represented by the pressure ratio of the pump


Section 1

- · Air pilot operated spool provides automatic cycling of air from one side of the piston to the other
- At the end of each stroke, the air piston activates a pilot valve that will cause the spool to shift

Section 2

- · The spool shifting will supply air to one side of the piston while venting the other side of the piston
- · This alternating action continues until the pump reaches its stall pressure










Typical Pump Cut-Away



	Description
Α	Air Inlet
В	Top End Cap
С	Air Muffler
D	Air Cylinder
E	Bottom End Cap
F	High Pressure Outlet Connection
G	Outlet Check Valve
Н	Pilot Valve

	Description
I	Air Piston Bumper
J	Air Piston
K	High Pressure Seal Assembly
L	Liquid Inlet Connection
М	Inlet Check Valve
N	Pump Head Body
0	Hydraulic Plunger

Parker Autoclave &





Pump Special Features & Benefits

- · All Aluminum parts machined from high quality bar stock, not cast aluminum components
- · Anodizing with special sealing technique to provide better protection from harsh environments
- · Muffler specified to give a great combination of high flow and low noise
- · Rubber bumpers in end caps to reduce noise of operation
- · Latest lubrication technology provides long seal service life and improves pump efficiency and performance
- · No lubricator required for air drive source
- · Stainless steel tie-rods and hardware
- · Stainless plunger coated with a proprietary multi-layer carbon based coating with diamond like carbon exterior layer:
 - High hardness (3 times harder than Stellite)
 - Inert, it has superior chemical compatibility and corrosion resistance
 - Low friction that limits seal wear and increases efficiency (coefficient of friction equal to or less than PTFE)
 - Tough coating that provides long plunger cycle life.
- · Pressure head specially designed and engineered for high cycle life
- · Spring energized U-cup seal provides better sealing performance at wide ranges of pressures
- Extended service life check valves with Ceramic balls for high pressure applications







ASL SERIES Single-Acting, Single or Double Piston Air Drive



Features:

- Pressure Ranges from 1,600 to 60,000 psi (110 to 4100 bar) max
- Operating Temperature Range: 0° to 140°F (-18° to 60°C)
- · Pressure Head Material: 15-5 PH Stainless Steel
- · Plunger: Stainless Steel, coated with proprietary multi-layer carbon for long life
- · Liquid Side Material: All Stainless Steel Construction
- · Air Side Material: Anodized Aluminum

Technical Data:

- Liquid Connections: Side Inlet Only see chart (page 9)
- Isolation Chamber: Only available on ASL400-02 pump
- Displacement per stroke: See chart (page 9)
- · Liquid Seals:

ASL10 to ASL35 = UHMWPE U-Cup and FKM Orings (PV option) ASL60 to ASL400 – UHMWPE U-Cup w/Elgiloy Spring Energizer

- Air Drive Pressure Range: 15-150 psi (1-10 bar) * See Note
- Main Air Inlet: ½" FNPT (Regulated)
- Pilot Air Inlet: 1/8" FNPT (unregulated)
- Max Air Consumption: 70 SCFM @ 90 psi (no pressure)
- · Pre-Lubricated Piston at Factory
- · Air Seals: Buna-N

Note: *Maximum air drive pressure is limited by maximum pressure shown in chart on Page 9.








ASL Pump Part Number Matrix

For complete information on available pump options, contact Parker Autoclave Engineers.

ASL400-02 -1:796*



ASL400-01 - 1:398 Note: Individual Pump Specifications can be found at www.Autoclave.com.

Reference Guide

		Maximum Rated	GPM	Liquid Connections			
Catalog Number	Pressure Ratio	Outlet Pressure PSI (bar)	Displacement Per Cycle .in³ (cm³)	Inlet	Outlet		
ASL10-01SNXX	1:11	1,600 (110)	5.22 (85.5)	1" FNPT	1/2" FNPT		
ASL25-01SNXX	1:28	4,000 (276)	2.10 (34.4)	1/2" FNPT	1/2" FNPT		
ASL35-01SNXX	1:39	5,600 (386)	1.50 (24.64)	1/2" FNPT	1/2" FNPT		
ASL60-01SNXX	1:70	10,000 (689)	0.84 (13.8)	1/2" FNPT	1/2" FNPT		
ASL100-01SNXX	1:113	15,000 (1,034)	0.52 (8.5)	1/2" FNPT	1/2" FNPT		
ASL150-01SNXX	1:150	21,500 (1,482)	0.39 (6.4)	1/2" FNPT	1/4" F250C		
ASL250-01SNXX	1:265	38,400 (2,648)	0.22 (3.6)	1/2" FNPT	1/4" F250C		
ASL400-01SCXX	1:398	57,700 (3,978)	0.14 (2.3)	1/2" FNPT	1/4" F250C		
ASL35-02SNXX	1:78	11,200 (772)	1.50 (24.64)	1/2" FNPT	1/2" FNPT		
ASL60-02SNXX	1:140	20,000 (1,379)	0.84 (13.8)	1/2" FNPT	9/16" SF562CX		
ASL100-02SNXX	1:226	31,000 (2,137)	0.52 (8.5)	1/2" FNPT	1/4" F250C		
ASL150-02SNXX	1:300	43,000 (2,965)	0.39 (6.4)	1/2" FNPT	1/4" F250C		
ASL400-02SCXX	1:796	60,000 (4,137	0.14 (2.3)	1/2" FNPT	1/4" F250C		










Air Drive Connection


All ASL Series Pumps have a 1/2" FNPT regulated main air drive supply connection and utilize a 1/8" FNPT pilot port connection for remote start/stop operation. It is recommended to operate the pilot port at a higher air pressure unregulated than the main air drive supply pressure for proper function.



^{*}See following page for product dimensions.







Single Piston

- Each mounting bracket includes (2) x 11/32" (8.73) slots for 5/16" bolts.
- · All dimensions are for reference only and are subject to change without notice.
- · Primary dimensions: Inches, Secondary Dimensions: (Millimeters)







ASL Series: Dimensions

Catalog Number	A _S	B _S	Cs
Single Piston Air Drive	1		
ASL10-01	6.87 (175)	8.25 (210)	9.83 (250)
ASL25-01	6.87 (175)	8.25 (210)	9.83 (250)
ASL35-01	6.87 (175)	8.25 (210)	9.83 (250)
ASL60-01	6.87 (175)	8.31 (211)	9.25 (235)
ASL100-01	6.87 (175)	8.31 (211)	9.25 (235)
ASL150-01	6.87 (175)	8.31 (211)	9.25 (235)
ASL250-01	6.87 (175)	8.31 (211)	9.25 (235)
ASL400-01	6.87 (175)	8.37 (213)	9.39 (239)

Catalog Number	A _D	B _D	C _D
Davible Dieten Air Driv			
Double Piston Air Driv	e 		
ASL35-02	ASL35-02 10.81 (275)		13.77 (350)
ASL60-02	10.81 (275)	12.25 (311)	13.19 (335)
ASL100-02	10.81 (275)	12.25 (311)	13.19 (335)
ASL150-02	10.81 (275)	12.25 (311)	13.19 (335)
ASL400-02	10.81 (275)	12.30 (312)	13.32 (338)

Note:

Each mounting bracket includes two (2) x 13/32" (10.32) slots for 3/8" bolts. Bottom inlet pump head and side inlet pump head are mutually exclusive. All dimensions are for reference only and are subject to change without notice.

Primary Dimensions: Inches Secondary Dimensions: (Millimeters)





Flow Rate Table: Air Drive Pressure (psi) vs. Outlet Pressure (psi)

Catalog	Air Drive					Ou	tlet Pres	ssure (p	si)				
Number	Pressure (psi)	0	500	1,500	3,000	5,000	7,500	10,000	15,000	25,000	40,000	55,000	
	60	1277	489										
ASL10-01	90	305	826										
	120	1360	925										-
	60	508	342	127									
ASL25-01	90	520	387	303									
	120	543	427	360	202								
	60	315	273	121									
ASL35-01	90	322	291	211	58								
	120	328	302	250	157								
	60	168	155	125	79								
ASL60-01	90	175	161	134	106	63							
	120	182	167	140	118	94	45						
	60	104	99	88	70	46							
ASL100-01	90	108	103	92	78	65	44	11					
	120	112	106	95	83	72	60	47					
	60	81	79	76	66	49	19						
ASL150-01	90	83	82	80	75	67	53	35					
	120	84	83	82	78	73	66	55	25				
	60	46	45	44	42	37	26	20	2				ir
ASL250-01	90	47	46	45	44	43	40	36	26				m
	120	48	47	47	46	45	43	41	34	17			
	60	39	38	37	36	33	29	23	10				
ASL400-01	90	40	39	38	38	37	35	32	26	8			
	120	41	40	39	38	38	37	36	32	21			
	60	240	230	210	115								
ASL35-02	90	242	232	225	190	115							
	120	245	235	230	210	170	95						
	60	150	148	145	120	70	2						
ASL60-02	90	155	152	147	136	117	80	33					
	120	157	154	152	145	133	112	82	8				
	60	86	84	82	77	72	53	30					
ASL100-02	90	87	86	84	82	82	70	61	36				
	120	89	88	86	84	84	77	72	57	13			
	60	64	64	63	60	57	50	38	14				
ASL150-02	90	65	65	64	62	60	57	53	41	9			
	120	66	66	65	64	63	61	58	51	32			
	60	31	31	30	30	29	29	28	26	16			
ASL400-02	90	31	31	31	30	30	30	29	27	23	14	2	
	120	31	31	31	31	30	30	30	29	27	21	14	

12 Parker Autoclave



ACHL SERIES Single-Acting, Single Air Drive with Hand Lever



Manual Operation

Air Driven Pump includes Hand Lever for manual operation or precise pressure control, remote locations, or emergency back-up.

Features:

- Pressure Ranges from 12,500 (860 bar) or 31,900 psi (2200 bar) maximum
- Operating Temperature Range: 0° to 140°F (-18° to 60°C)
- · Liquid Side Material: All Stainless Steel Construction
- · Air Side Material: Anodized Aluminum

Technical Data:

- · Liquid Connections: Side Inlet Only see chart (page 14)
- Displacement per stroke: See chart (page 14)
- · Liquid Seals: UHMWPE U-Cup w/Elgiloy Spring Energizer
- Air Drive Pressure Range: 15-150 psi (1-10 bar) * See Note
- Main Air Inlet: 1/4" FNPT (Regulated)
- Exhaust port (muffler removed) 1/4" FNPT
- · Air Seals: Buna-N
- · Pre-lubricated at Factory


Note: *Maximum air drive pressure is limited by maximum pressure, see rating show above.







ACHL Pump Part Number Matrix



Note: Individual Pump Specifications can be found at www.Autoclave.com.

Reference Guide

Catalag	Draggura	Maximum Rated	Displacement	Liquid Connections			
Catalog Number	Pressure Ratio	Outlet Pressure PSI (bar)	Per Cycle .in³ (cm³)	Inlet	Outlet		
ACHL72-01SNX	1:84	12,500 (862)	0.09 (1.47)	3/8" FNPT	1/4" F250C		
ACHL189-01SNX	1:213	31,900 (2,199)	0.035 (0.57)	3/8" FNPT	1/4" F250C		


Flow Rate Table: Air Drive Pressure (psi) vs. Outlet Pressure (psi)


Catalog Number	Air Drive		Outlet Pressure (psi)										
	Pressure (psi)	0	500	1,500	3,000	5,000	7,500	10,000	15,000	25,000	40,000	55,000	
ACHL72-01SNX	60	42	32	17	9	1							
	90	42	34	25	18	7	1						in ³ /
	120	43	35	29	24	17	7	2					min.
	60	15	15	15	15	14	13	8					
ACHL189-01SNX	90	15	15	15	15	15	13	11	7				
	120	15	15	15	15	15	13	12	8	1			





Air Drive Connection

All ACHL Series Pumps have a 1/4" FNPT regulated main air drive supply connection









Note:

- Each Mounting Bracket includes (2) 11/32" (8.73) holes for 5/16" Bolts.
- · Spool air tubing not shown for clarity.
- ${\boldsymbol \cdot}$ All dimensions are for reference only and are subject to change without notice.
- · Primary Dimensions: Inches
- · Secondary Dimensions: (Millimeters)







AFL SERIES Double-Acting, Single Piston Air Drive



Features:

- Pressure Ranges from 5,600 to 15,000 psi (385 to 1035 bar) max
- Operating Temperature Range: 0° to 140°F (-18° to 60°C)
- · Pressure Head Material: 15-5 PH Stainless Steel
- · Plunger: Stainless Steel, coated w/proprietary multi-layer carbon for long life
- · Liquid Side Material: All Stainless-Steel Construction
- · Air Side Material: Anodized Aluminum

Technical Data:

- · Liquid Connections: Bottom Inlet Only see chart (page 17)
- · Isolation Chamber: Standard on all sizes
- Displacement per stroke: See chart (page 17)
- · Liquid Seals: UHMWPE U-Cup w/ optional o-rings (see P/N matrix)
- Air Drive Pressure Range: 15-150 psi (1-10 bar) * See Note
- · Main Air Inlet: 3/4" FNPT (Regulated)
- Pilot Air Inlet: 1/8" FNPT (unregulated)
- Exhaust Port (muffler removed) 1" FNPT
- · Max Air Consumption: 167 SCFM @ 90 psi
- · Pre-Lubricated Piston at Factory
- · Air Seals: Buna-N


Note: *Maximum air drive pressure is limited by maximum pressure shown in chart on Page 17.







AFL Pump Part Number Matrix



Note: Individual Pump Specifications can be found at www.Autoclave.com.

Reference Guide

Catalag	Duasassus	Maximum Rated	Displacement	Liquid Connections			
Number	Catalog NumberPressure RatioOutlet PS		Per Cycle in³ (cm³)	Inlet	Outlet		
AFL35-1DBCXX	1:39	5,600 (386)	6.02 (98.7)	1" FNPT	9/16" SF562CX		
AFL60-1DBCXX	1:70	10,000 (690)	3.40 (55.7)	1" FNPT	9/16" SF562CX		
AFL100-1DBCXX	1:113	15,000 (1034)	2.30 (37.7)	1" FNPT	9/16" SF562CX		

Flow Rate Table: Air Drive Pressure (psi) vs. Outlet Pressure (psi)


Catalog	Air Drive Outlet Pressure (psi)									
Number	Pressure (psi)	0	500	1,500	3,000	4,500	6,000	10,000	15,000	
	60	24	19	9						
AFL35	90	25	21	16	6					
	120	26	23	19	12	2				
	60	14	12	9	4					Liters /
AFL60	90	14	13	11	8	6	1			min.
	120	15	14	12	10	8	6			
	60	10	9	7	5	3	1			
AFL100	90	11	10	8	7	6	5	1		
	120	12	11	9	8	7	6	3		





Air Drive Connection

All AFL Series Pumps have a 1/2" FNPT regulated main air drive supply connection and utilize a 1/8" FNPT unregulated pilot port connection for remote start/stop operation. It is recommended to operate the pilot port at a higher air pressure than the main air drive supply pressure for proper function.



Note:

- Each Mounting Bracket includes (2) 9/16" (14.29) holes for 1/2" Bolts.
- · All dimensions are for reference only and are subject to change without notice.
- · Primary Dimensions: Inches
- · Secondary Dimensions: (Millimeters)







AHL SERIES Double-Acting, Double Piston Air Drive



Features:

- Pressure Ranges from 6,700 to 22,500 psi (460 to 1550 bar) max
- Operating Temperature Range: 0° to 140°F (-18° to 60°C)
- · Pressure Head Material: 15-5 PH Stainless Steel
- Plunger: Stainless Steel, coated w/proprietary multi-layer carbon for long life
- · Liquid Side Material: All Stainless-Steel Construction
- · Air Side Material: Anodized Aluminum

Technical Data:

- · Liquid Connections: Dual Side Inlet Only see chart (page 20)
- · Isolation Chamber: Standard on all sizes
- Displacement per stroke: See chart (page 20)
- Liquid Seals: Thermoplastic Polyester U-Cup w/ optional o-rings (see P/N matrix)
- Air Drive Pressure Range: 20-100 psi (1.5-7 bar) * See Note
- · Main Air Inlet: 1" FNPT (Regulated)
- Pilot Air Inlet: 1/8" FNPT (unregulated)
- Exhaust Port (muffler removed) 1" BSP
- Max Air Consumption: 290 SCFM @ 50 psi (no pressure)
- Pre-Lubricated Piston at Factory
- · Air Seals: Buna-N


Note: *Maximum air drive pressure is limited by maximum pressure







AHL Pump Part Number Matrix



Note: Individual Pump Specifications can be found at www.Autoclave.com.

Reference Guide

	Dunnan	Maximum Rated	Displacement	Liquid Connections	
Catalog Number	Pressure Ratio	Outlet Pressure PSI (bar)	Per Cycle .in³ (cm³)	Inlet	Outlet
AHL33-2DSCXX	1:67	6,700 (462)	15.3 (250.7)	1" FNPT	1/2" FNPT
AHL66-2DSCXX	1:133	13,300 (917)	7.8 (127.8)	1/2" FNPT	1/2" FNPT
AHL118-2DSCXX	1:239	22,500 (1551)	4.4 (72.1)	1/2" FNPT	SF562CX

Liquid Flow Rate vs. Outlet Pressure: AHL33-2DSC Series

Approximate Air Drive Pressure: 100 psi					
Pressure (PSI)	Pressure (PSI) Pressure (bar) Flow (gpm) Flow (liter/min)				
0	0	7.6* (see note 2)	28.8* (see note 2)		
1000	69	6.1	23.0		
2000	138	5.7	21.5		
3000	207	4.9	18.4		
4000	276	4.0	15.2		
5000	345	3.2	12.3		
6000	414	1.8	6.9		

Nominal Liquid Pressure (Stalled)				
Air Drive Pressure		Liquid Pressure		
PSI	bar	PSI	bar	
20	1.4	1340	92.4	
30	2.1	2010	138.6	
40	2.8	2680	184.8	
50	3.4	3350	231.0	
60	4.1	4020	277.2	
70	4.8	4690	323.4	
80	5.5	5360	369.6	
90	6.2	6030	415.8	
100	6.9	6700	461.9	



Liquid Flow Rate vs. Outlet Pressure: AHL66-2DSC Series

Approximate Air Drive Pressure: 100 psi				
Pressure (PSI)	Pressure (bar)	Flow (gpm)	Flow (liter/min)	
0	0	3.6* (see note 2)	13.7* (see note 2)	
1000	69	3.4	12.9	
2000	138	3.1	12.0	
3000	207	2.9	11.2	
4000	276	2.7	10.3	
5000	345	2.5	9.5	
6000	414	2.3	8.7	
7000	483	2.2	8.2	
8000	552	2.0	7.7	
9000	621	1.8	6.7	
10000	690	1.5	5.7	
11000	759	1.3	4.8	
12000	828	1.0	3.9	

Nominal Liquid Pressure (Stalled)					
Air Driv	Air Drive Pressure Liquid Pressure				
PSI	PSI bar		bar		
20	1.4	2660	183.4		
30	2.1	3990	275.2		
40	2.8	5320	366.9		
50	3.4	6650	458.6		
60	4.1	7980	550.3		
70	4.8	9310	642.1		
80	5.5	10640	733.8		
90	6.2	11970	825.5		
100	6.9	13300	917.2		

Liquid Flow Rate vs. Outlet Pressure: AHL118-2DSC Series

Approximate Air Drive Pressure: 100 psi				
Pressure (PSI)	Pressure (bar)	Flow (gpm)	Flow (liter/min)	
0	0	2.0	7.7	
2000	138	1.8	6.9	
4000	276	2.0	6.3	
6000	414	1.5	5.8	
8000	552	1.4	5.4	
10000	689	1.3	5.1	
12000	827	1.2	4.7	
14000	965	1.1	4.3	
16000	1103	1.0	3.8	
18000	1241	0.8	3.1	
20000	1379	0.6	2.3	
22500	1551	0.2	0.8	

Nominal Liquid Pressure (Stalled)				
Air Drive Pressure Liquid Pressure				
PSI bar		PSI	bar	
20	1.4	4780	329.6	
30	2.1	7170	494.4	
40	2.8	9560	659.1	
50	3.4	11950	823.9	
60	4.1	14340	988.7	
70	4.8	16730	1153.5	
80	5.5	19120	1318.3	
90	6.2	21510	1483.1	
95	6.6	22500	1551.3	

Note:1. Actual flow rates will vary depending on air flow capacity, downstream flow restrictions, and fluid type.
2. Flow valve at approximately 50 psi air drive pressure.








Air Drive Connection


All AHL series pumps have a 1" FNPT regulated main air drive supply connection and utilize a 1/8" FNPT unregulated pilot port connection for remote start/stop operation. It is recommended to operate the pilot port at a higher air pressure than the main air drive supply pressure for proper function.



Model	Α	В
AHL33	32.41 (823.21)	30.42 (772.41)
AHL66	32.66 (829.61)	30.16 (766.11)
AHL118	32.66 (829.61)	30.16 (766.11)

Note:

- · Each Mounting Bracket includes (2) 9/16" (14.29) holes for 1/2" Bolts.
- · All dimensions are for reference only and are subject to change without notice.
- · Primary Dimensions: Inches
- · Secondary Dimensions: (Millimeters)



Parker Autoclave



Parker's Motion & Control Technologies

At Parker, we're guided by a relentless drive to help our customers become more productive and achieve higher levels of profitability by engineering the best systems for their requirements. It means looking at customer applications from many angles to find new ways to create value. Whatever the motion and control technology need, Parker has the experience, breadth of product and global reach to consistently deliver. No company knows more about motion and control technology than Parker. For further information call 1-800-C-Parker.

MA	ARKET	KEY MA	ARKETS	KEY PRO	ODUCTS	
*	AEROSPACE	Aircraft Engines Commercial Commerical Transports Military Aircraft Regional Transports	Business and General Aviation Land-Based Weapons Systems Missiles and Launch Vehicles Unmanned Aerial Vehicles	Flight Control Systems & Components Fluid Conveyance Systems Fluid Metering Delivery & Atomization Devices Fuel Systems & Components	Hydraulic Systems & Com- ponents Inert Nitrogen Generating Systems Pneumatic Systems & Com- ponents Wheels & Brakes	
	CLIMATE CONTROL	Agriculture Food, Beverage and Dairy Precision Cooling Transportation	Air Conditioning Life Sciences & Medical Processing	Co2 Controls Electronic Controllers Filter Driers Hand Shut-Off Valves Hose & Fittings	Pressure Regulating Valves Refrigerant Distributors Safety Relief Valves Solenoid Valves Thermostatic Expansion Valves	
	ELECTRO- MECHANICAL	Aerospace Life Science & Medical Packaging Machinery Plastics Machinery & Converting Semiconductor & Electronics Factory Automation	Machine Tools Paper Machinery Primary Metals Textile Wire & Cable	AC/DC Drives & Systems Electric Actuators, Gantry Robots & Slides Electrohydrostatic Actuation Systems Electromechanical Actuation Systems Human Machine Interface	Linear Motors Stepper Motors, Servo Mo- tors Drives & Controls Structural Extrusions	
COO	FILTRATION	Food & Beverage Life Sciences Mobile Equipment Power Generation Transportation	Industrial Machinery Marine Oil & Gas Process	Analytical Gas Generators Compressed Air & Gas Filters Condition Monitoring Engine Air, Fuel & Oil Filtration & Systems	Hydraulic, Lubrication & Cool- ant Filters Process, Chemical, Water Microfiltration Filters Nitrogen, Hydrogen & Zero Air Generators	
	FLUID and GAS HANDLING	Aerospace Agriculture Bulk Chemical Handling Construction Machinery Food & Beverage Fuel & Gas Delivery	Industrial Machinery Mobile Oil & Gas Transportation Welding	Brass Fittings & Valves Diagnostic Equipment Fluid Conveyance Systems Industrial Hose	PTFE & PFA Hose, Tubing & Plastic Fittings Rubber & Thermoplastic Hose & Couplings Tube Fittings & Adapters Quick Disconnects	
	HYDRAULICS	Aerospace Aerial lift Agriculture Construction Machinery Forestry	Industrial Machinery Mining Oil & Gas Power Generation & Energy Truck Hydraulics	Diagnostic Equipment Hydraulic Cylinders & Ac- cumulators Hydraulic Motors & Pumps Hydraulic Systems Hydraulic Valves & Controls	Power Take-Offs Rubber & Thermoplastic Hose & Couplings Tube Fittings & Adapters Quick Disconnects	
	PNEUMATICS	Aerospace Conveyor & Material Handling Factory Automation Life Science & Medical	Machine Tools Packaging Machinery Transportation & Automotive	Air Preparation Brass Fittings & Valves Manifolds Pneumatic Accessories Pneumatic Actuators & Grip- pers Pneumatic Valves & Controls	Quick Disconnects Rotary Actuators Rubber & Thermoplastic Hose & Couplings Structural Extrusions Thermoplastic Tubing & Fittings Vacuum Generators, Cups & Sensors	
	PROCESS CONTROL	Chemical & Refining Food, Beverage & Dairy Medical & Dental	Microelectronics Oil & Gas Power Generation	Analytical Sample Conditioning Products & Systems Fluoropolymer Chemical Delivery Fittings, Valves & Pumps High Purity Gas Delivery Fittings, & Valves & Regulators	Instrumentation Fittings, Valves Regulators Medium Pressure Fittings & Valves Process Control Manifolds	
	SEALING and SHIELDING	Aerospace Chemical Processing Consumer Energy, Oil & Gas Fluid Power General Industrial	Information Technology Life Sciences Military Semiconductor Transportation	Dynamic Seals Elastomeric O-Rings Emi Shielding Extruded & Precision-Cut, Fabricated Elastomeric Seals	Homogeneous & Inserted Elastomeric Shapes High Temperature Metal Seals Metal & Plastic Retained Composite Seals Thermal Management	



Parker Worldwide

North America

USA - Corporate, Cleveland, OH Tel: +1 256 896 3000

USA - IPD, Huntsville, AL Tel: +1 256 881 2040 ipdcct@parker.com

USA - IPD, (Autoclave), Erie, PA Tel: +1 814 860 5700 ipdaecct@parker.com

CA - Canada, Grimsby, Ontario Tel +1 905-945-2274 ipd canada@parker.com

South America

AR - Argentina, Buenos Aires Tel: +54 3327 44 4129 falecom@parker.com

BR - Brazil, Diadema, SP Diadema, SP Tel: +55 11 4360 6700 falecom@parker.com

CL - Chile, Santiago Tel: +56 (0) 2 2303 9640 falecom@parker.com

MX - Mexico, Toluca Tel: +52 722 275 4200 contacto@parker.com

Asia Pacific

AU - Australia, Dandenong Tel: +61 (0)2 9842 5150 customer.service.au@parker.com

CN - China, Shanghai Tel: +86 21 2899 5000 INGtechnical.china@parker.com

HK - Hona Kona

IN - India, Mumbai Tel: +91 22 6513 7081-85

ID - Indonesia, Tangerang Tel: +62 2977 7900 parker.id@parker.com

- Japan, Tokyo Tel: +(81) 3 6365 4020 infophi@parker.com

KR - South Korea, Seoul Tel: +82 2 559 0400 parkerkr@parker.com

MY - Malaysia, Selangor Tel: +603 784 90 800 parkermy@parker.com

SG - Singapore Tel: +65 6887 6300 parkersg@parker.com

TH - Thailand, Bangkok Tel: +66 2 186 7000 phthailand@parker.com

TW - Taiwan, Taipei Tel: +886 2 2298 8987 enquiry.taiwan@parker.com

VN - Vietnam, Hochi Minh City Tel: +848 382 508 56 parker_viet@parker.com

Europe, Middle East, Africa

AE - UAE, Duba Tel: +971 4 812 7100 parker.me@parker.com

AT – Austria, Wiener Neustadt Tel: +43 (0)2622 23501-0 parker.austria@parker.com

AT - Eastern Europe, Wiener Neustadt Tel: +43 (0)2622 23501 900 parker.easteurope@parker.com

AZ - Azerbaijan, Baku Tel: +994 50 2233 458 parker.azerbaijan@parker.com

BE/LU - Belgium, Nivelles Tel: +32 (0)67 280 900 parker.belgium@parker.com

BG - Bulgaria, Sofia Tel: +359 2 980 1344 parker.bulgaria@parker.com

BY – Belarus, Minsk Tel: +48 (0)22 573 24 00 parker.belarus@parker.com

CH - Switzerland, Etov Tel: +41 (0) 21 821 87 00 parker.switzerland@parker.com

CZ - Czech Republic, Klecany Tel: +420 284 083 111 parker.czechrepublic@parker.com

DE - Germany, Kaarst Tel: +49 (0)2131 4016 0 parker.germany@parker.com

DK - Denmark, Ballerup Tel: +45 43 56 04 00 parker.denmark@parker.com ES - Spain, Madrid Tel: +34 902 33 00 01 parker.spain@parker.com

Tel: +358 (0)20 753 2500 parker.finland@parker.com

FR - France, Contamine s/Arve Tel: +33 (0)4 50 25 80 25 parker.france@parker.com

GR - Greece, Athens Tel: +30 210 933 6450 parker.greece@parker.com

HU - Hungary, Budapest Tel: +36 223 885 470 parker.hungary@parker.com

IE - Ireland, Dublin Tel: +353 (0)1 466 6370 parker.ireland@parker.com

IT - Italy, Corsico (MI) Tel: +39 02 45 19 21 parker.italy@parker.com

KZ – Kazakhstan, Almaty Tel: +7 7273 561 000 parker.easteurope@parker.com

NL - The Netherlands, Oldenzaal Tel: +31 (0)541 585 000 parker.nl@parker.com

NO - Norway, Stavanger Tel: +47 66 75 34 00 parker.norway@parker.com

PL - Poland, Warsaw Tel: +48 (0)22 573 24 00 parker.poland@parker.com PT - Portugal, Leca da Palmeira Tel: +351 22 999 7360 parker.portugal@parker.com

Tel: +40 21 252 1382 parker.romania@parker.com

RU - Russia, Moscow Tel: +7 495 645-2156 parker.russia@parker.com

SE - Sweden, Spånga Tel: +46 (0)8 59 79 50 00 parker.sweden@parker.com

SK – Slovakia, Banská Bystrica Tel: +421 484 162 252 parker.slovakia@parker.com

SL - Slovenia, Novo Mesto Tel: +386 7 337 6650 parker.slovenia@parker.com

TR - Turkey, Istanbul Tel: +90 216 4997081 parker.turkey@parker.com

UA - Ukraine, Kiev Tel: +48 (0)22 573 24 00 parker.ukraine@parker.com

UK - United Kingdom, Warwick Tel: +44 (0)1926 317 878 parker.uk@parker.com

ZA - South Africa, Kempton Park Tel: +27 (0)11 961 0700 parker.southafrica@parker.com

! CAUTION!

inge component parts or tubing with those of other manufacturers. Doing so is unsafe and will void warranty

d Tools are not designed to interface with common commercial instrument tubing and are designed to only connect with tubing manufactured to Parker Autoclave Engineers AES specifications. Failure to do so is unsafe and will void warranty.

WARNING

FAILURE, IMPROPER SELECTION OR IMPROPER USE OF THE PRODUCTS AND/OR SYSTEMS DESCRIBED HEREIN OR RELATED ITEMS CAN CAUSE DEATH, PERSONAL INJURY AND PROPERTY DAMAGE.

This document and other information from Parker Hannifin Corporation, its subsidiaries and authorized distributors provide product and/or system options for further investigation by users having technical expertise. It is important that you analyze all aspects of your application and review the information concerning the product or system in the current product catalog. Due to the variety of operating conditions and applications for these products or systems, the user, through its own analysis and testing, is solely responsible for making the final selection of the products and systems and assuring that all performance, safety and warning requirements of the application are met. The products described herein, including without limitation, product features, specifications, designs, availability and pricing, are subject to change by Parker Hannifin Corporation and its subsidiaries at any time without notice.

Offer of Sale

The items described in this document are available for sale by Parker Hannifin Corporation, its subsidiaries or its authorized distributors. Any sale contract entered by Parker will be governed by the provisions stated in Parker's standard terms and conditions of sale (copy available upon request).

©2022 Parker Hannifin Corporation | Autoclave Engineers is a registered trademark of the Parker Hannifin Corporation

www.parker.com/ipd





Instrumentation Products Division Autoclave Engineers Operation 8325 Hessinger Drive Erie, PA 16509-4679 Tel: 814 860 5700 Fax: 814 860 5811 www.autoclave.com

Instrumentation Products Division Headquarters 1005 A Cleaner Way Huntsville, AL 35805 USA Tel: 256 881 2040 Fax: 256 881 5072

Parker Hannifin Manufacturing Ltd. Instrumentation Products Division, Europe Riverside Road Pottington Business Park Barnstaple, UK, EX31 1NP, UK Tel: 44 1271 313131 Fax: 44 1271 373636

ISO-9001 Certified

April 2022

Air-Driven, High Pressure Liquid Pumps Product Catalog

Literature #: 02-9326BE